


G860-2.5

Parts Diagram



- G860001 Air Adj Knob
- G860002 Air Adj Screw
- G860003 Air Adj O-Ring
- G860004 Air Adj Washer
- G860005 Air Adj Spring
- G860006 Air Inlet Valve
- G860007 Switch Spring
- G860008 Air Inlet Valve Body
- G860009 Switch Knob
- G860010 Switch Knob O-Ring
- G860011 Switch Knob Washer
- G860012 Lock Knob
- G860018 Fluid Nozzle Joint
- G860019 Polypro Joint Washer
- G860020 Direction Screw
- G860021 Mat. Needle Washer
- G860022 Locking Spring
- G860023 Trigger Lever I
- G860024 Trigger Lever II
- G860025 Trigger

- G860026 Upper/Lower Snap Retainer
- G860028A Alum Cup Assy (1.0 L)
- G860028P Plastic Cup Assy (.06 L)
- G860030 Material Filter
- G860031 Mat Inlet Joint
- G860035 Fluid Needle Spring
- G860036 Mat Lock Nut
- G860037 Mat Adj Knob
- G860038 Pattern Phillips Screw
- G860039 Pattern Adj Knob
- G860040 Pattern Adj Screw
- G860041 Pattern Adj Washer
- G860042 Pattern Adj Screw
- G860043 Pattern Adj O-Ring
- G860044 Snap Retainer
- G860045 Air Inlet Joint
- G860046 Tool Wrench
- G860047 Hex Wrench
- G860049 Cleaning Brush
- G860017 Air Cap Seal