## **Application Guide**

## Compounding and Polishing Application: Aqua-Buff® Products



Use these Aqua-Buff® products to remove scratches from and polish composite patterns, plugs, masters and molds. Also use them to remove scratches from and to clean FRP parts, metals and painted surfaces.

Aqua-Buff 1000-F Fast-Cut Compound

Aqua-Buff 1000-W Fast Cut Compound

Aqua-Buff 2000 Compound and Polish

## Aqua-Buff 1000-F and 100-W Fast-Cut Compound

Spread Aqua-Buff 1000-F or 1000-W Fast Cut Compound on the surface to be compounded with a brush or cloth, several square feet at a time--using one-half the normal amount--and mist the surface with water. Immediately machine buff with a clean, damp compounding pad. Repeat the process to eliminate scratches from exceptionally hard surfaces. Should the compound become dry while being buffed, rewet again by misting the surface with water. Follow with Aqua-Buff 2000 Compound and Polish for the ultimate shine.

## Aqua-Buff 2000 Compound and Polish

Spread Aqua-Buff 2000 Compound and Polish on the surface to be compounded with a brush or cloth, several square feet at a time--using one-half the normal amount--and mist the surface with water. Immediately machine buff with a clean, damp lamb's wool-type pad. Repeat the process to eliminate scratches from exceptionally hard surfaces. (Or if you haven't done so, first use Aqua-Buff 1000-F or 1000-W Fast-Cut Compound). Should the compound become dry while being buffed, re-wet again by misting the surface with water.

**Note:** For best results, use machine buffers that generate at least 2500 rpm for Aqua-Buff products.



Hawkeye Industries Inc.

Revised 1-11-07

P O Box 415 Bloomington, CA 92316 Tel 909-546-1160; Toll Free 800-977-0060; Fax: 909-546-1161 Email productinfo@duratec1.com Web www. duratec1.com